

Francese Cutlery Set












Description

The Francese silver or silver-plated cutlery set was styled for highly elite tables. The set comes is characterized by lovely lined contours and an ornate decoration.























The distinctive grooved pattern of the handles makes the set highly original and innovative.

The perfectly balanced weight of the cutlery ensures very easy handling. Made and hand-finished in Italy.

Francese

	Table Fork 8"1/4		Fruit Fork 6"5/8
	Table Knife 9"7/8		Fruit Knife 8"1/4
	Table Spoon 7"7/8		Fruit Spoon 7"
	Steak Knife 8"1/4		Ice-Cream Spoon 5"1/8
	Soup Spoon 6"5/8		Tea Spoon 5"1/8
	Fish Fork 7"		Coffee Spoon (Large) 4"3/8
	Fish Knife 8"1/4		Coffee Spoon (Small) 4"
	Lobster Fork 7"		Cheese Knife 8"5/8
	Shellfish Knife 7"		Grated Cheese Spoon 4"3/4
	Dessert Fork 5"1/2		Parmesan Cheese Fork 5"7/8
	Dessert Knife 6"1/4		Parmesan Cheese Knife 6"1/4

Francese

	Soft Cheese Knife 9"		Cake Server 10"5/8
	Parmesan Cheese Slicer 8"1/4		Cake Server Knife 11"
	Parmesan Cheese Grater 9"		Salad Serving Fork 9"
	Serving Fork 9"7/8		Salad Serving Spoon 9"
	Serving Spoon 9"7/8		Bread Knife 11"3/8
	Rice Serving Spoon 11"3/8		Carving Knife 12"1/4
	Spaghetti Serving Spoon 12"5/8		Carving Fork 10"1/4
	Ladle 12"1/4		Poultry Sheers 10"1/4
	Lasagna Server 11"7/8		Sauce Ladle 5"7/8
	Fish Serving Fork 9"7/8		Spaghetti Tongs 9"
	Fish Serving Knife 11"		Bread Tongs 9"

Francese



Butter Knife
6"1/4



Ice-Cream Serving Spoon
7"7/8



Bottle Opener
5"7/8



Lemon Peeler
7"



Champagne Tongs
7"



Lobster Tongs
9"



Nut Cracker
6"5/8



Pizza Cutter
7"1/2



DISHWASHER
except cutlery with
parts in natural horn



use a delicate cycle max. 40° to 45°
with a mild detergent that does
not contain chlorine/additives



dry with a soft cloth



BY HAND



use a soft non-abrasive sponge
and mild detergent



rinse carefully



dry with a soft cloth