

# Inglese Cutlery Set






















## *Description*





















The luxury Inglese Set proposes the distinctive flair of premium English-style silverware remodelled over the centuries.

The perfectly balanced weight of the cutlery ensures very easy handling. Made and hand-finished in Italy.

## Inglese

	Table Fork 7"7/8		Fruit Fork 6"5/8
	Table Knife 9"7/8		Fruit Knife 8"1/4
	Table Spoon 7"7/8		Fruit Spoon 7"
	Steak Knife 8"1/4		Ice-Cream Spoon 5"1/8
	Soup Spoon 6"5/8		Tea Spoon 5"1/8
	Fish Fork 6"5/8		Coffee Spoon (Large) 4"3/8
	Fish Knife 8"1/4		Coffee Spoon (Small) 4"
	Lobster Fork 7"		Cheese Knife 8"1/4
	Shellfish Knife 7"		Grated Cheese Spoon 4"3/4
	Dessert Fork 5"1/2		Parmesan Cheese Fork 5"7/8
	Dessert Knife 6"1/4		Parmesan Cheese Knife 5"7/8

## Inglese

	Soft Cheese Knife 9"		Cake Server 10"5/8
	Parmesan Cheese Slicer 8"1/4		Cake Server Knife 11"
	Parmesan Cheese Grater 9"		Salad Serving Fork 9"
	Serving Fork 9"3/8		Salad Serving Spoon 9"
	Serving Spoon 9"3/8		Bread Knife 11"3/8
	Rice Serving Spoon 11"		Carving Knife 12"5/8
	Spaghetti Serving Spoon 12"5/8		Carving Fork 10"5/8
	Ladle 12"1/4		Poultry Sheers 10"1/4
	Lasagna Server 11"7/8		Sauce Ladle 5"7/8
	Fish Serving Fork 9"7/8		Spaghetti Tongs 9"
	Fish Serving Knife 11"		Bread Tongs 9"

## Inglese

	Ice Tongs 7"		Pizza Cutter 7"1/2
	Butter Knife 6"1/4		Hors Doeuvre Fork 5"1/2
	Ice-Cream Serving Spoon 7"7/8		Hors Doeuvre Knife 6"1/4
	Bottle Opener 5"7/8		Hors Doeuvre Spoon 4"3/4
	Lemon Peeler 7"		Hors Doeuvre Server 5"1/2
	Champagne Tongs 7"		
	Lobster Tongs 9"		
	Nut Cracker 7"		



DISHWASHER  
except cutlery with  
parts in natural horn



use a delicate cycle max. 40° to 45°  
with a mild detergent that does  
not contain chlorine/additives



dry with a soft cloth



BY HAND



use a soft non-abrasive sponge  
and mild detergent



rinse carefully



dry with a soft cloth